

Partnered for your convenience.

Alexa Voice Commands for the Lennox iComfort Skill

1. Set your device to a specific temperature:

- "Alexa, set (thermostat name) to (75) degrees"
- "Alexa, set (thermostat name) temperature to (75)"
- "Alexa, set (thermostat name) to (75)"
- "Alexa, change temperature to (75)" Alexa will ask you to confirm which device, just say your thermostat's name.
- "Alexa, turn temperature to (75)" Alexa will ask you to confirm which device, just say your thermostat's name.

2. Turn UP the temperature a set amount:

- "Alexa, increase (thermostat name) by (3) degrees"
- "Alexa, increase (thermostat name) temperature by (3) degrees"
- "Alexa, raise (thermostat name) by (3) degrees"
- "Alexa, heat up (thermostat name) by (3) degrees"

3. Turn UP the temperature by 2 degrees:

- "Alexa, increase (thermostat name) temperature"
- "Alexa, heat up (thermostat name)"
- "Alexa, make (thermostat name) warmer"

4. Turn DOWN the temperature a set amount:

- "Alexa, decrease (thermostat name) by (3) degrees"
- "Alexa, lower (thermostat name) temperature by (3) degrees"
- "Alexa, decrease (thermostat name) temperature by (3) degrees"
- "Alexa, cool down (thermostat name) by (3) degrees"

5. Turn DOWN the temperature by 2 degrees:

- "Alexa, lower (thermostat name) temperature",
- "Alexa, cool down (thermostat name)"
- "Alexa, make (thermostat name) colder"

6. Ask for the current temperature

• "Alexa, what is the temperature of (thermostat name)" Alexa will reply with current temperature.

7. Ask for thermostat setpoints

 "Alexa, what is the (thermostat name) set to?" Alexa will reply with the current thermostat setpoints and the thermostat mode (heat, cool or auto)